



VeneerBric™ Installation Instructions

VeneerBric sheets can be installed by roughly following industry standard wallpaper installation instructions. Listed below are recommended installation instructions for your reference.

1. Prepare the walls.

If you're hanging the sheet on new drywall, prime the wall first with wallpaper primer to seal the drywall and help the sheet adhere to the wall.

Wash any dirt or dust from the old walls and sand smooth any chipped paint.

Remove old wallpaper using wallpaper remover, a wide blade, and rags.

Remove electrical outlet and light switch covers.

Use a putty knife to apply spackle over holes or cracks. Allow the spackle to dry, then sand lightly until the surface is smooth.

2. Pick a starting point.

The first sheet will line up with the last sheet you hang and the pattern should match up at that place. You will want to start and finish installing sheets in a corner, near the curtains or behind a door so that the mismatch is less obvious. The focal point of the room should have the fewest seams.

Measure out from your starting point and use a level to lightly draw a vertical straight edge on the wall. This line marks where the first sheet should be placed.

3. Cut the sheet.

Lay the first sheet, print side up, on the flat work surface. Confirm the top and bottom of the pattern. Measure, and then cut the first sheet to the proper length. Measure and cut the next several sheets in order. The factory width edges (left and right) have pattern bleed over. This masks the white substrate so that when installing sheet to sheet, the seams are less noticeable. Cut out receptacle and other switch plates using sharp utility knife and customary industry practices.

4. Apply wallpaper paste.

Apply pre-mixed paste to the wall where the next sheet will be applied. Apply pre-mixed paste using a large pasting brush, paint roller, notched trowel, or as recommended by paste manufacturer. DO NOT apply paste to the veneer bric sheet. Be sure that all areas of the wall where the sheet is being applied to are covered with paste, with no un-pasted spots.

Select the proper adhesive for your application. Two wallpaper adhesives have been tested successfully with Veneer Bric sheets:

Pro 888 Ultra Plus from Roman

XT-2000+ from Formulated-Solutions

5. Hang the sheet.

The sheet can be rolled or folded in half and held, with the print facing the inside. Do not crease the sheet. Starting at the ceiling, carefully unfold or unroll the top portion of the first sheet and gently place the side edge of the strip along the measured line. Place a thumbtack in each corner at the top of the sheet to hold it in place.

When the sheet is in the right position, drop down the bottom portion and gently smooth the sheet against the wall with your hands, beginning at one edge and working your way across. Use a smoothing brush, damp sponge, or J-roller to smooth out any air bubbles. Use a seam roller to gently smooth down the edges of the sheet.

6. Smooth the corners.

At the corners, measure from the last sheet to the corner. Cut the next sheet to that width. Apply paste to the wall as mentioned in section 4.

NOTE: Inside or outside corner trim pieces might be necessary to properly finish these areas.

Apply the sheet on the wall, making sure to smooth it totally into the corner for interior corners.

7. Repeat hanging the sheets around the room.

Continue hanging the next sheet, taking care to match the pattern, removing any creases or air bubbles, securing the seams, and cleaning the paste off the sheet.

8. Replace light switch and receptacle plates.**MAINTENANCE**

The following materials and instructions are recommended for cleaning VeneerBric:

- Lint brush
 - 2 Small bowls
 - Water
 - Liquid clothes soap
 - 3 Hand towels
1. Brush the fabric with the lint brush. This will help to remove lint, dust, dirt and debris and soften any hard spots.
 2. Dab at any wet spots with a hand towel. Do not rub, as this can spread the spill or the stain and make it more difficult to remove.
 3. Fill a small bowl with water and dip the end of the second hand towel into it. Wring out any excess moisture.
 4. Dab the wet hand towel at any spot of stain on the VeneerBric. Do not rub.
 5. Pour a small amount (silver dollar sized amount) of liquid clothing detergent into the second bowl.
 6. Dip the end of the wet hand towel into the detergent and dab at the stain or spot, until it is removed. Do not rub.
 7. Dip the end of the third hand towel into water and wring out any excess moisture.
 8. Dab the wet hand towel over the area you just cleaned with detergent. Repeat until the soap is gone.
 9. Dab at the wet spot with the dry end of the hand towel until it has dried.

For specific stains and their cleaning recommendation, please see the guide below:

STAIN	RECOMMENDED CLEANING SOLUTIONS
BEER	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water / white vinegar (3 oz.)
BERRY	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water / ammonia (4-8 oz.)
BIRD DROPPINGS	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water, or try Goo Gone Grease Cutter (a hand cleaner), Greased Lightning, or Clean Rite Purple Power (available at Wal-Mart, K-Mart, etc.)
BLOOD (DRIED)	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water / ammonia (4-8 oz.)
BUTTER	Volatile solvent (acetone) 100%
CHARCOAL, PENCIL MARKS	Vacuum, then Dawn [®] dishwashing liquid (2 oz.)/1 gallon water
CATSUP OR MUSTARD	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water
CHEWING GUM	Volatile solvent (acetone) 100%
CHOCOLATE	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water / ammonia (4 oz.)
COFFEE	Dawn [®] dishwashing liquid /water, white vinegar, volatile solvent (acetone)
COLA	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water
CRAYON	Paint remover (100%), oil or grease remover (mix as directed)
EGG (RAW)	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water
GRAPE JUICE	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water
GRAVY	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water
GREASE (CAR)	Volatile solvent (acetone) 100%
INK (PERMANENT, INDIA, BALLPOINT)	Paint remover (100%), volatile solvent (acetone) 100%, soap and water
IRON RUST	Carbona [™] Stain Devil #9
LIPSTICK	Paint remover, oil or grease remover (mix as directed)
MASCARA	Paint remover (100%), volatile solvent (acetone-100%), Dawn [®] dishwashing liquid (2 oz.)/1 gallon water
MILDEW	Bleach (1 cup) / Dawn [®] dishwashing liquid (2 oz.)/1 gallon water
MILK	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water
NAIL POLISH	Volatile solvent (acetone) 100%
OIL	Volatile solvent (acetone) 100%
ORANGE DRINK	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water
PAINT (LATEX) WET	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water
PAINT (LATEX) DRIED	Paint remover (100%), oil or grease remover (mix as directed)
PAINT (OIL OR LACQUER)	Paint remover (100%), oil or grease remover (mix as directed)
SHOE POLISH (LIQUID)	Volatile solvent (acetone) 100%
SHOE POLISH (WAX)	Apply heated iron over towel, volatile solvent (acetone) 100%
SUNTAN LOTION	Pine Power [®] or pine oil detergent / water (mix as directed)
TEA	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water
TOMATO JUICE	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water
TREE SAP	Turpentine (100%), Dawn [®] dishwashing liquid (2 oz.)/1 gallon water
URINE	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water / white vinegar (3 oz.)
VOMIT	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water / white vinegar (3 oz.)
WATER COLOR	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water / white vinegar (3 oz.)
WAX (CANDLE)	Apply heated iron over towel, volatile solvent (acetone) 100%
WINE	Dawn [®] dishwashing liquid (2 oz.)/1 gallon water / ammonia (4-8 oz.)/ white vinegar (3 oz.)

CONDITIONS & WARRANTY

Advanced Technology, Inc. believes all information contained herein to be correct. It is the responsibility of the fabricator/customer to completely test the adhesives and methods of fabrication to ensure that the results are satisfactory. ATI is not responsible for any fabrication or ancillary costs involved with using VeneerBric products.

All shipments are to be inspected within 10 working days after delivery. We are to be informed in writing of any potential adjustment necessary. The seller's only obligation will be to replace defective sheets on a one to one basis. Neither the manufacturer nor the seller shall be liable for any additional damage or loss, directly or indirectly, arising as a result of using VeneerBric products.

Slight imperfections and color variations from sheet to sheet are possible and considered normal. Please inspect each sheet carefully before fabrication to ensure it meets your needs.